Fuel - Alternate blinking red/white LED

Published 06/13/2002

Symptom(s):

Fans running
No video
Alternate blinking red and white LED

Fact(s):

Silicon Graphics Fuel

SGI Solution:

Test another keyboard/mouse, as the system will stop at PROM if console is set to "ioc3", and it does not find a keyboard.

Reseat the odyssey graphics assembly, inspect the connectors for any visible damage.
If after reseating the odyssey graphics assembly the problem persists, replace it, or if there is visible damage to the connectors on the motherboard or the graphics were replaced and the problem continues,otherwise, we may need to replace the IP34 motherboard.

NOTE: This is NOT a Customer Replaceable Component, an SGI field engineer will have to execute this procedure, for any additional troubleshooting assistance please contact your support provider.

Cause(s):

Graphics configuration error at power up

Additional Details

Creation Date	02/05/2002 04:27 AM
Last modification	01/15/2016 04:29 PM
Published Date	06/13/2002
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution